

INSTRUCTIONS

309829H



Zip Clean 2525




This manual contains important warnings and information.
READ AND KEEP FOR REFERENCE.

INSTRUCTIONS

Model 246602, Series A and B

2300 psi (159 bar, 15.8 MPa) Maximum Operating Pressure

2500 psi (172 bar, 17.2 MPa) Maximum Working Pressure



CE

Table of Contents

| | |
|--|----|
| Symbols | 2 |
| Warnings | 3 |
| Component Identification | 4 |
| Pressure Relief Procedure | 6 |
| Installing and Changing Spray Tips | 11 |
| Pump Service | 18 |
| Parts Drawing | 21 |
| Parts List | 22 |
| ASM Phone Number | 24 |

Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow instructions.

Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow instructions.



WARNINGS

**Fuel Hazard:**

Fuel is combustible. When spilled on a hot surface it can ignite and cause a fire. Do not fill fuel tank while engine is running or hot.

**Exhaust Hazard:**

Exhaust contains poisonous carbon monoxide, which is colorless and odorless. Do not operate this equipment in a closed building.

**Equipment Misuse Hazard:**

Misuse of pressure washer or accessories can cause the equipment to rupture or malfunction and result in serious injury.

- Do not alter or modify any part or factory-setting
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not exceed maximum working pressure (MWPR) of the lowest-rated system component
- Use fluids and solvents that are compatible with the equipment wetted parts. See Specification on page for this information.
- Wear hearing protection when operating this equipment.
- Do not “blow back” fluid; this is not an air spray system
- Follow **Pressure Relief**, page 6 before cleaning, checking or servicing equipment.

**TOXIC FLUID HAZARD:**

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in eyes or on skin, inhaled, or swallowed.


- Know specific hazards of fluids you are using and take protective measures as recommended by the fluid and solvent manufacturer.

**Skin Injection Hazard:**

Spray from gun, leaks or ruptured components can inject fluid into your body and cause serious injury. Fluid splashed in eyes or on skin can also cause serious injury.

- Fluid injected into skin might look like just a cut, but it is a serious injury. **Get immediate surgical treatment.**
- Do not point gun at anyone or any part of the body.
- Do not stop or deflect leaks with hand, body, glove, or rag.
- Do not put your hand or fingers over the spray tip.
- Tighten fluid connections before you start this equipment.
- Engage the gun safety whenever you stop spraying.
- Follow **Pressure Relief Procedure**, page 6 if the spray tip clogs and before you clean, check or service this equipment.
- Repair or replace worn or damaged parts immediately.
- Check hoses, tubes, and couplings daily. Do not repair high-pressure couplings. Replace entire hose. Fluid hoses must have spring guards on both ends to prevent kinks and rupture.

Component Identification




Setup

Shipping Damage

Check pressure washer for shipping damage. Notify carrier immediately if there is any damage.


Connect High-Pressure Hose and Gun

Connect high-pressure hose between the pump outlet and gun inlet.




Install Spray Tip


Install spray tip on wand. Installing and Changing Spray Tips, page 11). If you are using a Sandblasting Kit, see its separate manual for installation instructions.



Connect to Water Supply

Connect hose with at least a 3/4 in. (19 mm) ID from water supply to 3/4 in. garden hose inlet on the pressure washer. The supply hose should not be more than 50 ft (15 m) long.

| |
|--|
|  CAUTION |
| Before you connect garden hose to pressure washer, check local plumbing codes regarding cross-connection to water supply. If required, install backflow preventer. |
| If inlet water pressure is over 60 psi (4.1 bar), a regulating water valve must be installed at garden hose connection. |
| Do not exceed 104° F (40° C) inlet water temperature. |




Note: Water source must have a minimum flow rate equal to that of pressure washer.




PRESSURE RELIEF

Follow these instructions whenever you are instructed to relieve pressure, stop spraying for more than 10 minutes, check or service the equipment, or install or clean the spray nozzle.

1. Engage trigger safety latch




2. Turn pressure washer off




3. Remove ignition cable from spark plug.

4. Shut off water supply. Disconnect from water.



5. Disengage trigger safety latch. Trigger gun to relieve pressure. Then re-engage the safety latch.



Note: If you suspect that the spray tip or hose is clogged or that pressure has not been fully relieved after following the steps above, disengage the trigger safety latch and trigger the gun to relieve pressure.

Operation

Startup


Always use this startup procedure to ensure that the pressure washer is started safely and properly.

- Always engage gun trigger safety latch when you stop spraying. This reduces the risk of fluid injection or splashing in eyes or on skin if gun is bumped or accidentally triggered.
- Always observe the CAUTIONS in this section to avoid costly damage to pressure washer.
- If you use the Sandblaster Kit, see Sandblaster Kit Manual for detailed cleaning information.


-
1. Check oil level of engine.



-
2. Check fuel level.




-
3. Turn on water supply.




CAUTION

Never run pressure washer without water. Costly pump damage will result. Always be sure water supply is completely turned on before you run pressure washer.


4. Trigger gun until a constant stream of water sprays from tip indicating air is purged from the system.



5. Be sure spark plug ignition cable is pushed firmly onto spark plug.



7. Pull the starter rope quickly to start the engine. Pull and return the rope until the engine starts. HINT: Placing one foot on the pressure washer as a brace provides better leverage.





NOTE: For easier starting, have one person start pressure washer while another triggers gun.

| CAUTION |
|---|
| <ul style="list-style-type: none">● Do not allow pressure washer to idle more than 10 minutes. This causes circulating water to overheat and serious damage to the pump. The pump is equipped with a thermal valve to help prevent severe damage if circulating water is overheating.● Turn off pressure washer if it will not be spraying at least every 10 minutes or if thermal valve activates. If heated inlet water is used, reduce this time.● Do not operate pressure washer with inlet water screen removed. This screen helps keep abrasive sediment which could clog pump or damage cylinders, out of pump.● Do not pump caustic materials. |

Trigger Safety Latch

Always engage the safety latch when you stop spraying.

Always engage trigger safety latch when you stop spraying even for a moment. The engaged safety latch prevents the gun from being triggered accidentally by hand or when dropped or bumped. Be sure latch is pushed fully down or it will not prevent the gun from being triggered.




Chemical Injector Operation

1. Follow **Pressure Relief Procedure**, page 6.



-
2. Push end of chemical injector hose over chemical injector fitting on pump. Place other end in container of chemical solution.



-
3. Install the black, large-orifice, chemical tip. (**Installing and Changing Spray Tips** page 11).
 4. Trigger gun for a few seconds. Chemical solution will begin mixing in spray pattern.

The large orifice of the chemical tip causes a drop in pressure that actuates the chemical injector. Changing back to a small orifice spray tip deactivates the chemical injector and produces high pressure for rinsing. The chemical filter can be left in the chemical container during high-pressure use.

Installing and Changing Spray Tips

Spray tips have 4– or 5–digit numbers on them. The first two digits are the spray angle. Tip holding holes are provided on the chassis.

| Spray Tip Number | Spray Pattern Fan Angle |
|------------------|-------------------------|
| 00XXX | 0° blaster (red) |
| 15XXX | 15° (yellow) |
| 25XXX | 25° (green) |
| 40XXX | 40° (white) |
| Chemical | XX° (black) |

NOTE: The chemical injector tip is brass and has a large opening and a black plastic cap.


1. Perform **Pressure Relief Procedure**, page 6.



2. Point the gun and wand away from you and anyone else.



3. Lock trigger safety.
4. Without holding your hand over spray tip (A), pull back quick coupler ring (B). Remove current tip. Install a different one. Then push the ring back on.



CAUTION

To avoid blowing the o–ring out of the quick coupler due to the high pressure in the system, never operate pressure washer without a tip securely mounted in quick coupler.


Shutdown, Flushing, and Storage

1. Remove chemical injector hose from pump, if attached.


2. Trigger gun for one minute to flush pump with clear water.




3. Engage trigger safety.




4. Adjust throttle to STOP position. Engine should turn off.




5. Shut off water supply. Disconnect water supply hose from pump.




6. Remove trigger safety latch and trigger gun to relieve pressure.



7. Remove high pressure hose from pump. Drain water from all components.



-
- After each use, wipe all surfaces of pressure washer with a clean, damp cloth.



Long Term (more than 30 days)/Winter Storage

- Do not store unit outside where it can be exposed to rain, dirt or adverse weather conditions.
- Do not expose pressure washer to freezing temperatures or allow water to freeze in pressure washer components, causing the pump to lock-up. If this happens let pump thaw naturally in WARM ENVIRONMENT. DO NOT attempt to speed up this process by pouring warm water on pump. This could cause further damage.

ENGINE:

1. Run engine until gas is gone or stabilize the fuel and run it through the fuel system and carburetor.
2. Drain water out of pressure washer hose.
3. Turn fuel system to OFF position.

Pump:

4. Attach one end of a 4 or 5-foot section of hose to pump inlet and other end in an antifreeze solution approximately 1-foot off the ground.
5. Pull pull-cord on engine until antifreeze comes out of pump outlet.

Storage Location:

6. Store pressure washer in garage, basement or other area where it is protected from freezing temperatures.

Maintenance Chart



Perform **Pressure Relief Procedure** (page 6).

| Interval | What to do |
|---|--|
| Daily | Clean water inlet screen and filter. Check engine and pump oil levels. Fill as necessary. Check gasoline level. Fill as necessary. |
| After first 5 hours of operation | Change engine break-in oil. Drain oil when warm. Use SAE 30 or 10W–30 detergent oil. |
| Every 3 months or 25 hours of operation | Clean and remove air cleaner foam. Wash with water and detergent. Dry thoroughly. Rub with oil, and squeeze to distribute oil. |
| Every 6 months or 50 hours of operation | Change engine oil. Use Use approved SAE30 or 10W30 detergent oil. |
| After every 100 hours of operation, or every 3 months | Check/adjust spark plug and idle speed. Clean fuel tank and filter.. |

NOTE: It is not necessary to change pump oil during the life of the pump. If pump oil is drained for repair, use part number 117784 replacement oil only.

Troubleshooting



Perform **Pressure Relief Procedure** (page 6).

| Problem | Cause | Solution |
|--|--|--|
| Engine will not start or is hard to start. | No gasoline in fuel tank or carburetor | Fill tank with gasoline, open fuel shutoff valve. Check fuel line and carburetor. |
| | Low oil | Add oil to proper level. |
| | Throttle in STOP position | Move throttle to FAST (rabbit) position |
| | Water in fuel or old fuel | Drain fuel tank and carburetor. Use new fuel and make sure spark plug is dry. |
| | Engine flooded or improperly choked | Open choke, pull engine starter rope several times to clear out fuel. Make sure spark plug is dry. |
| | Dirty air cleaner filter | Remove and clean. |
| | Spark plug dirty, wrong gap, or wrong type | Clean, adjust gap or replace. |
| | Gun not triggered | Trigger gun while starting engine. |
| Engine misses or lacks power | Partially plugged air cleaner filter | Remove and clean. |
| | Spark plug dirty, wrong gap, or wrong type | Clean, adjust gap or replace. |
| Pressure is too low and/or pump runs roughly | Worn or wrong size tip | Replace with tip of proper size. |
| | Inlet filter clogged | Clean. Check more frequently. |
| | Worn packings, abrasives in water, or natural wear | Check filter. Replace packing. |
| | Inadequate water supply | Check water flow rate to pump. |
| | Fouled or dirty inlet or discharge valves | Clean inlet and discharge valve assemblies. Check filter. |
| | Restricted inlet | Garden hose might be collapsed or kinked. |
| | Worn inlet or discharge valves | Replace worn valves. |
| | Leaking high-pressure hose | Replace high-pressure hose. |
| Water leaks from under pump manifold | Worn packings | Install new packings. |
| | Loose fitting connections | Check all fitting connections. Tighten if loose. |
| Water on oil side of pump | Worn packings | Install new packings. |
| | Oil seals leaking | Install new oil seals. |

| Problem | Cause | Solution |
|--|---|--|
| Packings are failing frequently or prematurely | Scored, damaged, or worn plungers | Install new plungers. |
| | Abrasive material in fluid being pumped | Install proper filtration on pump inlet plumbing. |
| | Inlet water temperature too high | Check water temperature. It should not exceed 104°F (40°C). |
| | Overpressurizing pump | Do not modify any factory-set adjustments. |
| | Excessive pressure due to partially plugged or damaged tip | Clean or replace tip. See Installing and Changing Spray Tips (page 11). |
| | Pump running too long without spraying | Never run pump more than 10 minutes without spraying. |
| | Running pump dry | Do not run pump without water. |
| Strong surging at inlet and low pressure on discharge side | Foreign particles in inlet or discharge valve or worn inlet and/or discharge valves | Clean or replace valves. |
| Water spitting out of thermal valve | Pump running too long without spraying | Trigger gun to get fresh, cooler water in pump. |

Note: For complete pump repair and design information see website: www.ARNORTHAMERICA.com

Pump Service

Repair kits are available. See the **Parts Lists** (page 21). For the best results, use all parts in the kits.



Perform **Pressure Relief Procedure** (page 6).

Servicing Valves

Discharge Valves:

Disassembly

1. Remove valve cap.
2. Inspect valve cap o-ring for damage. Replace if necessary.
3. Using a needle nose pliers, remove valve.
4. Use a small probe to move the poppet up and down to assure it is functioning properly.
5. Inspect for any debris that may be lodged between poppet and seal.
6. Remove valve seat o-ring and inspect for damage.

Assembly

1. Install valve seat o-ring squarely into bottom of manifold.
2. Insert valve assembly squarely into port, pushing it into o-ring.
3. Install valve cap and torque to 443 in.-lbs (37 ft-lbs).

Inlet Valves

Disassembly

1. Remove manifold.
2. Remove low-pressure seals by inserting a flat screwdriver under seal lip and lifting up.
3. Using a reversible pliers, carefully remove packing retainers (plunger guides).

Note: Packing retainers can be reused if not worn.

4. Remove high-pressure packing by pulling straight out with your finger.
5. Pull out valve cage/head ring assembly, valve poppet, spring and o-ring.
6. Inspect for debris and/or damage.
7. Remove valve o-ring.

Assembly

1. Install valve seat o-ring squarely into bottom of manifold.
2. Insert valve assembly and push squarely into o-ring.
3. Install high-pressure packing by placing it into cylinder at an angle and then pushing into place.

Note: The point of the “v” or flat side of packing is pointed at you.

4. Lubricate packing retainer o-ring with a light film of oil and install it into cylinder.
5. Push it completely into place.

Note: O-ring will seat just inside manifold and you will hear a slight pop.

6. Insert low-pressure seal by placing it into cylinder at an angle and pushing it into place.
7. Put a thin coat of oil on plungers and packings.
8. Carefully install manifold and torque bolt to 443 in.-lbs (37 ft-lbs).

Note: Valve life is dependant on many variables. Hard water, cavitation, corrosion, chemicals and equipment care. The valves are a wear item and need periodic replacement. Worn o-rings or damaged valves will cause pressure loss and pulsations.

Packings

Disassembly

1. To access water seals for inspection or replacement, remove head of pump.

Note: It is important to note the order in which the components of the packing stack are arranged and facing during disassembly.

2. Remove head bolts.
3. Insert a small pry bar between head and body at opposite corners and apply pressure down on one pry bar and up on the other pry bar.
4. Lift head up and away from body.

Note: Packing stack will not always stay in head of pump when it is removed. Sometimes one or more components of the packing stack will come out of the head and stay on the plunger.

5. To remove any components that stay on plungers twist back and forth while pulling up.
6. Remove low-pressure seals by inserting a flat screwdriver under seal lip and lifting up.
7. Remove piston guides from head by using a reverse pliers (preferably rubber coated) inserted into center of piston guide.
8. Use back and forth twisting motion while pulling up (clockwise and counter-clockwise).
9. Another method is to use a two-prong slide hammer puller. Insert prongs into piston guide allowing prongs to grab under support ring, then use slide hammer to pull packing stack up and out of head.

Note: Damage to piston guides and or seals may occur during removal. Inspect carefully before reusing any components of packing stack.

10. Remove high-pressure packing by pulling straight out with your finger.

Assembly

1. Install high-pressure seal into head.

Note: It should fit snugly. The packing support is part of the valve cage.

2. Place high-pressure seal at an angle and work it into cylinder.

Note: The point of the “v” or flat side of packing is pointed at you.

3. Lubricate packing retainer o-ring with a light film of oil and install it into cylinder.

4. Push it completely into place.

Note: O-ring will seat just inside manifold and you will hear a slight pop.

5. Insert low-pressure seal by placing it into cylinder at an angle and pushing it into place.


6. Put a thin coat of oil on plungers and packings.

7. Carefully install manifold and torque bolt to 443 in.-lbs (37 ft-lbs).

Note: Valve life is dependant on many variables. Hard water, cavitation, corrosion, chemicals and equipment care. The valves are a wear item and need periodic replacement. Worn o-rings or damaged valves will cause pressure loss and pulsations.

Water seals are wear items. Lift of seals is dependent on many factors. Water seals should be replaced when water leak or loss of performance is noticed. Prompt replacement of worn seals will insure peak operating performance and trouble-free operation.

Parts



Parts

| Ref. No. | Part No. | Description | Qty. | Ref. No. | Part No. | Description | Qty. |
|----------|----------|-----------------------|------|----------|----------|----------------------|------|
| 1 | 15C311 | HANDLE, cart | 1 | 20 | 118000 | ENGINE, 5 hp, Honda | 1 |
| 2 | 15C312 | FRAME, placard | 1 | 21 | 110837 | SCREW, hex hd | 4 |
| 3 | 15C307 | RACK, hose | 1 | 22 | 111040 | NUT, nylon | 6 |
| 4 | 115651 | NUT, acorn | 2 | 23 | 197792 | KEY, motor shaft | 1 |
| 5 | 805535 | TIP, 0°, red | 1 | 24 | 118122 | PUMP (with bolts) | 1 |
| 6 | 805536 | TIP, 15°, yellow | 1 | 25 | 117758 | ADAPTER, garden hose | 1 |
| 7 | 805538 | TIP, 40°, white | 1 | 26 | 117759 | VALVE, thermal | 1 |
| 8 | 805634 | TIP, chemical, black | 1 | 27 | 117760 | HOSE, injector | 1 |
| 9 | 801012 | GROMMET | 4 | 28 | 118125 | HOSE | 1 |
| 10 | 112827 | BUTTON, snap | 2 | 29 | 246674 | GUN | 1 |
| 12 | 15C308 | FRAME, cart, Series A | 1 | 30 | 118124 | EXTENSION, gun | 1 |
| | 287611 | FRAME, cart, Series B | 1 | 31 | 116477 | WASHER | 2 |
| 13 | 116968 | WHEEL | 2 | 32▲ | 290013 | LABEL, warning | 1 |
| 14 | 101242 | RING, retaining | 2 | 33▲ | 290131 | LABEL, warning | 1 |
| 15 | 287609 | FRAME, leg, Series B | 1 | 34▲ | 802363 | LABEL, caution | 1 |
| 16 | 113817 | FOOT, base, rubber | 2 | 35 | 100270 | SCREW, cap, hex hd | 2 |
| 17 | 100057 | SCREW, hex, cap | 2 | 36 | 102040 | NUT, lock | 2 |
| | | | | 37 | 116411 | SPRING | 2 |
| | | | | 45 | 100527 | WASHER | 4 |

▲ Additional danger and warning tags and labels available free.

Repair Kits

| | | |
|--------|----------------------------|---|
| 287131 | KIT, repair, water seals | 1 |
| 287132 | KIT, repair, valves | 1 |
| 287133 | KIT, repair, pistons | 1 |
| 287134 | KIT, repair, oil seals | 1 |
| 287135 | KIT, repair, o-rings | 1 |
| 287136 | KIT, repair, unloader | 1 |
| 287137 | PUMP (includes 24, 25, 26) | 1 |
| 117784 | OIL, pump | 1 |

Technical Data

| | |
|--------------------------------|---|
| Working pressure range | |
| Operating Pressure | 2300 psi (159 bar, 15.8 MPa) |
| Maximum Working Pressure | 2500 psi (172 bar, 17.2 MPa) |
| Engine horsepower | 5.0 |
| Maximum delivery (with nozzle) | 2.4 gpm |
| High pressure hose | 30 ft x 5/16 in. supplied |
| Chemical injector hose | 4 ft (m) 1/4 in. ID |
| Weight, pressure washer only | 60 lb (27.22 kg) |
| Weight: sprayer, hose and gun | 73 lb (33.11 kg) |
| Dimensions | |
| | 23.5 in. (59.69 cm) Length |
| | 22.0 in. (55.88 cm) Width |
| | 22.0 (55.88 cm) Height |
| Pump inlet fitting | 3/4 in. internal thread (standard garden hose thread) |
| Stoorage temperature range* | -30° to 160°F (-35° to 71°C) |
| Operating temperature range | 40° to 115°F (4° to 46°C) |

*When pump is stored with non-freezing fluid.

ASM Standard Warranty

ASM warrants all equipment referenced in this document which is manufactured by ASM and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized ASM distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by ASM, ASM will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by ASM to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with ASM's written recommendations.

This warranty does not cover, and ASM shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-ASM component parts. Nor shall ASM be liable for malfunction, damage or wear caused by the incompatibility of ASM equipment with structures, accessories, equipment or materials not supplied by ASM, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by ASM.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized ASM distributor for verification of the claimed defect. If the claimed defect is verified, ASM will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

ASM's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

ASM MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY ASM. These items sold, but not manufactured by ASM (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. ASM will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will ASM be liable for indirect, incidental, special or consequential damages resulting from ASM supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of ASM, or otherwise.

FOR ASM BRAZILIAN/CANADIAN/COLUMBIAN CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English.

TO PLACE AN ORDER OR FOR SERVICE, contact your ASM distributor,
or call 1-800-854-4025 to identify the nearest distributor.

All written and visual data contained in this document reflects the latest product information available at the time of publication. ASM reserves the right to make changes at any time without notice.

mm 309829

ASM Company, 3500 North 1st Avenue, Sioux Falls, SD 57104

www.asmcompany.com

PRINTED IN USA 309829 3/2003, Revised 02/2006